



When the installation is complete we recommend you spray-mist the surface with water to stimulate the curing process. In the event that there is a possibility of rain you should spray-mist the surface with water as you go. Tape off the direct area and inform your clients of the required dry-cure time. It would be wise to create a sign off sheet and take some picture of the finished site so that there are no misunderstandings regarding any damage that has occurred during the curing process. This will protect you in the event of foot traffic caused by humans and animals on the surface before it is completely cured.

This concludes the basic installation training manual. Please accompany this manual with the video to further assist you in the installation process.

