

START THE MIXING:

Assuming your dry rubber has been pre-mixed to achieve the proper look/color you can begin the mixing process.

Take one bag of rubber (Solid color bag 45KG-55lbs not mixed from the supplier for accuracy) and pour evenly into two clean 5 gallon pails. Pour the rubber into the buckets side by side until they are completely even. Take a permanent marker and draw a line around the inside of the bucket, just above the level of the rubber inside one of the buckets. (See Diagram below) You have accurately marked half a bag so you can now mark and use the pail as rubber measuring pail.

For each mix you will measure one marked pail of dry mixed rubber mixed with 2 litres of resin. Depending on the capacity of your mixer you may be able to mix higher volumes.

Pour the rubber into the mixer and turn the mixer on. Slowly and evenly pour the resin into the mixer and allow at least two minutes of mixing time to ensure the resin and rubber have been mixed thoroughly. Do not mix over three minutes (Saturation can occur causing clumps of rubber and resin to be formed). When the rubber and resin is mixed and the mixer has been shut off, sift through the mix by hand to ensure there are no dry granules and the mixture is completely uniform.

You are now ready to begin installing the Rubber Surfacing.

